



- 1. Battery
- 2. Starter-generator
- 3. Condenser
- 4. Ignition circuit breaker
- 5. Ignition coil
- 6. Spark plug

- 7. Accelerator micro switch
- 8. Directional key switch
- 9. Solenoid switch
- 10. Voltage regulator
- 11. Overload circuit breaker
- 12. Reverse buzzer
- 13. Diode

Figure 8-1. Wiring Diagram